



THIS DETAIL IS REQUIRED FOR ALL FLEECE-BACK MEMBRANE AND OPTIONAL FOR ALL SYSTEMS LISTED BELOW

**NOTE:**

1. FOR INSULATION THICKNESS GREATER THAN 8", CONTACT RPI TECHNICAL SERVICES FOR ALTERNATE ATTACHMENT REQUIREMENTS.
2. FOR HEAT WELDING LAPS, USE 1 1/2" WELD WITH ROBOT WELDER AND 2" WHEN USING A HAND HELD WELDER.
3. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED EDGES. (REFER TO CUT EDGE SEALANT DETAIL)

## RE-FLEX TPO COVER STRIP HEAT WELD END LAP DETAIL

ACCEPTABLE WITH RE-FLEX TPO MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#303



Roofing Products International, Inc.