



NOTE:

1. T-JOINT PATCH REQUIRED FOR .045/.060/.080 RE-FLEX TPO MEMBRANE.
2. HEAT WELD 1 1/2" LAP WHEN USING ROBOT (AUTOMATIC) WELDER AND 2" WELD WHEN HAND WELDING.
3. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED MEMBRANE EDGES. (REFER TO RE-FLEX TPO CUT EDGE SEALANT DETAIL)

RE-FLEX TPO HEAT WELD END LAP DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#304

