



NOTE:

1. T-JOINT IS TO BE USED FOR .060/080 MIL TPO.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT MEMBRANE EDGES.
(REFER TO CUT EDGE SEALANT DETAIL)

TRIMMING OF OVERLYING SEAM
EDGE IS NOT REQUIRED

RE-FLEX TPO T-JOINT COVER PATCH HEAT WELD DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#305

