



**NOTE:**

1. FOR HEAT WELDING LAPS USE 1 1/2 " WELD WITH AUTOMATIC MACHINE WELDER.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT TPO EDGES. (REFER TO RE-FLEX TPO CUT EDGE SEALANT DETAIL)

## RE-FLEX TPO HEAT WELD SIDE LAP DETAIL

ACCEPTABLE WITH RE-FLEX TPO  
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#306

