



**NOTE:**

1. ANY CHANGE OF SLOPE 2:12 OR GREATER MUST BE MECHANICALLY ATTACHED AT ANGLE CHANGE.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED TPO EDGES.  
(REFER TO CUT EDGE SEALANT DETAIL)

## RE-FLEX TPO CHANGE OF PLANE DETAIL

ACCEPTABLE WITH RE-FLEX TPO  
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#308

