



NOTE:

1. RE-FLEX CUT EDGE SEALANT MUST BE USED ON ALL FIELD CUT MEMBRANE EDGES.

RE-FLEX CUT EDGE SEALANT DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#310

