



FOR ALTERNATE TAPERED ROOF EDGE,
USE APPROVED TAPERED INSULATION

NOTE:

1. ADD BALLAST PER BALLASTED SPECIFICATION SYSTEM.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED RE-FLEX TPO MEMBRANE EDGES.

RE-FLEX COATED METAL EDGE DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#312

