



SECTION

NOTE:

1. ADD APPROVED BALLAST PER BALLAST SYSTEM INSTALLATIONS.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED TPO EDGES.

SNAP ON FASCIA METAL EDGE DETAIL

ACCEPTABLE WITH RE-FLEX TPO MECHANICALLY
ATTACHED OR BALLAST SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#314

