



NOTE:

1. METAL AND MEMBRANE MUST BE CLEANED WITH MEMBRANE CLEANER BEFORE APPLYING PRIMER AND COVER TAPE.
2. THIS DETAIL IS NOT TO BE USED ON SLOPES GREATER THAN 1/12.

METAL EDGE WITH RE-FLEX TPO COVER TAPE DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#315

