



**NOTE:**  
 APPLY RE-FLEX LAP CAULK OR RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED  
 MEMBRANE EDGES. REFER TO CUT EDGE SEALANT OR RE-FLEX LAP CAULK DETAIL.

## RE-FLEX TPO COVER TAPE ON METAL EDGE - CORNER CAULK DETAIL

ACCEPTABLE WITH RE-FLEX TPO  
 MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#317

