



NOTE:

1. TERMINATION BAR MUST BE USED IN ALL PRESSURIZED SYSTEMS.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT MEMBRANE EDGES.
3. PLATES AND FASTENERS MAY BE USED IN LIEU OF TERMINATION BAR IN NON-PRESSURIZED INSTALLATIONS.

ALTERNATE WALL/BASE FLASHING TERMINATION DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#321

