



NOTE:

1. APPLY RE-FLEX CUT-EDGE SEALANT TO ALL FIELD CUT REINFORCED MEMBRANE EDGES.

COATED METAL WALL FLASHING DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#322

