



NOTE:

1. INSTALL RE-FLEX PREFORMED OR UNREINFORCED CORNERS TO ALL FOUR SCUPPER CORNERS.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED MEMBRANE EDGES.
3. IF COATED (WELDABLE) METAL IS NOT AN OPTION, THE MEMBRANE MUST BE ADHERED TO THE SCUPPER BOX USING RPI BONDING ADHESIVE.

COATED METAL SCUPPER WALL FLASHING DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#323

