



**NOTE:**

1. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED MEMBRANE EDGES.

## OUTSIDE CORNER WALL FLASHING WITH COATED METAL DETAIL

ACCEPTABLE WITH RE-FLEX TPO  
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#324

