



**NOTE:**

1. ADD BALLAST PER BALLAST SYSTEM SPECIFICATIONS.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT MEMBRANE EDGES.

## PREFORMED RE-FLEX EXPANSION JOINT WALL DETAIL-FLAT INSTALLATION

ACCEPTABLE WITH RE-FLEX TPO MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#330

