



**NOTE:**

1. ADD BALLAST PER BALLAST SYSTEM SPECIFICATIONS.
2. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT MEMBRANE EDGES.

## INSULATED METAL CURB FLASHING TERMINATION DETAIL

ACCEPTABLE WITH RE-FLEX TPO  
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#331

