



NOTE:

1. CUT BOOT TO ALLOW FOR SNUG FIT WHEN SLIDING OVER PIPE.
2. IF PLATES AND FASTENERS INTRUDE UNDER WELDED PIPE FLANGE, A TARGET PATCH MUST BE INSTALLED EXTENDING 2" PAST THE PLATES.
3. APPLY RE-FLEX CUT EDGE SEALANT TO ALL FIELD CUT REINFORCED MEMBRANE EDGES.

PREFORMED PIPE BOOT FLASHING DETAIL

ACCEPTABLE WITH RE-FLEX TPO
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#334

