



NOTE:

1. THE ROOF PROJECTION MUST BE CLEAN OF ANY EXISTING DEBRIS OR OTHER MATERIAL PRIOR TO INSTALLATION OF NEW FLASHINGS.
2. INSIDE WALL OF POCKET MUST BE PRIMED BEFORE ADDING POURABLE SEALER.
3. ALLOW FOR 2" CLEARANCE BETWEEN THE PROTRUSION AND THE POCKET SIDE WALL. FOR MULTIPLE PROTRUSIONS, ALLOW A MINIMUM OF 1" BETWEEN PROTRUSIONS.
4. IF POCKET MUST BE CUT, THE CUT MUST BE FLASHED WITH UNREINFORCED FLASHING MEMBRANE EXTENDING A MINIMUM OF 2" PAST THE CUT AND ONTO THE DECK A MINIMUM OF 2".
5. DO NOT ALLOW PLATES AND FASTENERS TO ENCROACH INTO THE 2" HEAT WELD LAP AREA. IF PLATES ARE WITHIN THE LAP AREA, A TARGET PATCH MUST BE INSTALLED BEFORE THE PITCH POCKET IS INSTALLED.

POURABLE PITCH POCKET DETAIL

ACCEPTABLE WITH RE-FLEX TPO FULLY ADHERED AND
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#336

