



NOTE:

1. SPLICE FLASHING MUST BE NON-REINFORCED RE-FLEX TPO FLASHING MEMBRANE.
2. SPLICE MUST BE INSTALLED AND EXTEND (HEAT WELDED) INTO THE POCKET PRIOR TO FILLING THE PITCH POCKET.
3. SEALER IS ADDED TO ELIMINATE ANY STANDING WATER ON THE PITCH POCKET.

POURABLE PITCH POCKET WITH SPLICE DETAIL

ACCEPTABLE WITH RE-FLEX TPO FULLY ADHERED AND
MECHANICALLY ATTACHED SYSTEMS

PROJECT:

SCALE

NOT TO SCALE

Revision Date: 5-10-2015

#337

