

Get the Royal Edge Advantage with RPI



Re-Flex EPDM Cured Cover Tape

RPI RE-FLEX EPDM

DESCRIPTION

RPI Re-Flex EPDM Cured Cover Tape membrane is a white nominal 60 mil cured EPDM membrane laminated to a 30 mil fully cured tape adhesive. Re-Flex Cured Cover Tape is designed for use in new or re-roof low slope single-ply membrane systems for flashing in metal drip edge, gravel stops, and other flashings outline in the RPI Specification Manual.



THE RPI ROYAL EDGE ADVANTAGE

- Available in 6" x 100', 9" x 50', and 12" x 50' rolls.
- May be warmed for easier application during cold weather applications.
- Clear release liner won't tear like brown paper liner.
- Excellent long term performance.
- Approved for use on RPI EPDM and TPO membranes.
- 12" wide rolls are pre-slit on center for ease of installation when installing wide flashings.

APPLICATION INSTRUCTIONS

RPI Re-Flex EPDM is designed to be installed as part of a fully adhered system using RPI adhesives, Flashings, Tapes, and other accessories. Refer to the RPI Specification Manual or Application Handbook for more complete installation details.

1. All membranes and substrates must be clean, dry, and free of dirt, dust, and oils. Before applying Seam Tape Primer, clean all metal flashings with Membrane cleaner to remove any residual manufacturing oils or other contaminants.
2. Apply RPI Re-Flex Seam Tape Primer. On Royal Edge Clean Sheets, the Seam Tape Primer can be applied using a 3/8" nap roller. On any aged or talc sheet membranes, Seam Tape Primer must be applied using RPI Scrub Pads after the membrane has been thoroughly cleaned with Membrane Cleaner.
IMPORTANT: Do not over apply the Seam Tape Primer. The finished primed surface should have a smooth flat sheen. Excessive primer will not enhance the adhesion of the tape.
3. Allow the primed area to "flash-off". Check the primer using the finger-push method. Do not attempt to apply any flashings to primed areas that have not sufficiently flashed-off.
4. Remove the required area of release liner and mate the tape membrane surface to the primed area. Starting in the middle of the flashing piece to minimize air pockets, mate the membrane to the primer using an even, firm, hand pressure.

5. Using a 2" steel or hypalon hand roller, roll the entire flashing from the middle of the flashing to the edges.
6. Apply Lap Sealant at required flashing edges and intersections.
7. To ensure complete and proper adhesion in cold weather applications (temperatures of 50° F or lower), keep the flashings stored in a room temperature until installation. The primed area and flashing membrane may be warmed with a hot-air gun while installing the flashings.
8. RPI Re-Flex Cured Cover Tape is the required flashing for multiple applications in RPI Royal Edge EPDM systems.

Refer to the RPI Specification Manual or Application Handbook for more complete information.

Typical Properties and Characteristics

Color	White
Base Membrane Adhesive	EPDM Synthetic Rubber
Ozone resistance condition after exposure to 100 pphm Ozone in air for 168 hours @ 104°F (40°C). Specimen under 50% strain.	No cracks
Normal Width Membrane Adhesive	6" , 9" , 12" 6 3/16" , 9 3/16" , 12 3/16"
Normal Thickness	88 mil
Brittleness Temperature	-49°F (-45°C)
Packaging	6"x 100' 2-rolls per carton 9"x50' 1-roll per carton 12"x 50' 1-roll per carton
Net Weight Per Roll	6" roll = 30 lbs 9" roll = 24 lbs 12" roll = 32 lbs
Shelf Life	12 months when stored between 60°-80°F (15°-27°C)

Note: Roofing Products International Re-Flex EPDM Cover Tape Membrane meets or exceeds the minimum requirements set forth by ASTM D4811 for Type I, Class V flashing material.

Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.

Get the Royal Edge Advantage with RPI



Re-Flex EPDM Cured Cover Tape

RPI RE-FLEX EPDM

PRECAUTIONS

Keep out of reach of children.

Avoid prolonged contact with skin. In case of skin contact, wash the affected area with soap and water.

Do not allow petroleum, grease, oil, solvents, vegetable or mineral oils, animal fats etc. or direct steam venting to come into contact with Re-Flex flashing.

In warm sunny weather, keep flashings in the original shipping box in a shaded area until ready to use.

Hot Weather

Do not allow storage temperatures to exceed 90° F.

Keep material in a shaded area, out of direct sunlight.

High storage temperatures will shorten the product shelf life.

Cold Weather

Storage or use in temperatures below 50° F require the material be warmed to room temperature before use. Temperatures below 40° F may result in the complete loss of tack.

If the ambient temperature is near the dew point, condensation may form as the Seam Tape Primer flashes off. When this condition occurs, all use of primers and adhesives should stop. When applicable conditions return, the previously primed area should be thoroughly dried and re-primed.

Warming or Hot Boxes may be required for onsite storage.

A hot air gun may be used to warm the material during a cold weather application. Warming the primed area as the flashing is applied and mated to the primed area will ensure proper adhesion.

LEED® Information

Pre-consumer Recycled Content	4%
Post-consumer Recycled Content	0%
Manufacturing Location	Greenville, IL
Solar Reflectance Index	N/A